

INSTALLATION INSTRUCTIONS

LAST UPDATE 2026	VEHICLE TYPE G-CLASS FROM 2018
---------------------	-----------------------------------

MADE IN GERMANY



TABLE OF CONTENTS

1. General. 3

1.1 Safety instructions 3

1.2 Scope of delivery 4

2. Assembly 5

2.1 Vehicle preparation. 5

2.2 Preparation wind deflector 7

2.3 Assembly wind deflector. 12

Please note: You will also need the CAN bus module fitting instructions and the roof rack fitting instructions.

1. GENERAL

Thank you for purchasing a LETECH quality product. Through state-of-the-art production facilities, constant checks and regulated processes, we ensure that only flawless products leave our production.

1.1 SAFETY INSTRUCTIONS

Work on the vehicle may only be carried out by trained specialists.

Work on the vehicle electrical system may only be carried out by specialists with appropriate electrical and electronic knowledge.

Before working on the vehicle electrical system, disconnect the battery.

Use suitable hoists and tools when preparing and assembling the LETECH wind deflector.

In general, the safety requirements of the respective workshop or country must be observed.

1.2 SCOPE OF DELIVERY

Wind deflector

(1x)

M8x25 Torx Screws

(4x)

Washers

(4x)

Spacer plates

(4x)

Foam tape (34cm)

(2x)

High-beam headlights Vision X

(2x)

Work lights Vision X

(2x)

Wiring harness wind deflector

(1x)

2. ASSEMBLY

2.1 VEHICLE PREPARATION



Before fitting the wind deflector, it is advisable to install the CAN bus module first. (Separate installation instructions for the CAN bus module)

For the 465 model, remove the A-pillar trim, roof spoiler and upper trim strip on the right-hand side. For the 463A model, remove only the A-pillar trim on the right-hand side.

2.1 VEHICLE PREPARATION



Make a cut-out for the cable feed-through 4.5 cm from the end.
Adjust the cladding and lay the cable on the roof. Stick the cladding back in place.

2. ASSEMBLY

2.2 PREPARATION WIND DEFLECTOR



Fit the headlamps to the wind deflectors, ensuring the correct arrangement: high-beam headlamps on the inside and work lights on the outside. Align the headlamps and tighten them.

2.2 PREPARATION WIND DEFLECTOR



Place the cable in the designated recesses and secure it. Drill a hole in the plug and the end of the cable using a 7mm drill bit at a suitable point and secure it with a clip. (See photo)

2.2 PREPARATION WIND DEFLECTOR



Secure the plug to the headlamp bracket using cable ties.
Ensure the cables are routed correctly.

2.2 PREPARATION WIND DEFLECTOR



Stick the supplied foam tape to the inside of the wind deflector, on the right and left.

2.2 PREPARATION WIND DEFLECTOR



Degrease the bonding area and apply suitable double-sided adhesive tape.

2.3 ASSEMBLY WIND DEFLECTOR



Fit the wind deflector. Connect the plug.

2.3 ASSEMBLY WIND DEFLECTOR



Align the wind deflector on the roof rack without applying any tension, using the four spacer plates. Fit four M8x25 Torx screws with washers and apply 'Loctite Blue' threadlocker, then tighten to a maximum of 10 Nm.

2.3 ASSEMBLY WIND DEFLECTOR



Functional test of the lighting.