

INSTALLATION INSTRUCTIONS

LAST UPDATE 2025	VEHICLE TYPE GRENADIER
---------------------	---------------------------

MADE IN GERMANY



TABLE OF CONTENTS

1. General. 3

1.1 Safety instructions 3

1.2 Scope of delivery 4

2. Assembly 5

1. GENERAL

Thank you for purchasing a LETECH quality product. Through state-of-the-art production facilities, constant checks and regulated processes, we ensure that only flawless products leave our production.

1.1 SAFETY INSTRUCTIONS

Work on the vehicle may only be carried out by trained specialists.

Work on the vehicle electrical system may only be carried out by specialists with appropriate electrical and electronic knowledge.

Before working on the vehicle electrical system, disconnect the battery.

Use a suitable tool when preparing to install the LETECH winch cover.


In general, the safety requirements of the respective workshop or country must be observed.

1.2 SCOPE OF DELIVERY


Screw M6x25
(2x)



Sheet metal nut
(2x)



LETECH winch cover
(1x)




2. ASSEMBLY



Loosen the two screws of the original winch cover and extend the cover from the bumper.


(A Phillips screwdriver can be used as a tool.)

2. ASSEMBLY



<p>Sheet metal nut (2x)</p>	<p>Pull out the original sheet metal nuts and replace them with the threaded clips included in the delivery.</p>
---------------------------------	--

2. ASSEMBLY




Remove the sprues in the bumper with a suitable tool.

(A knife can serve as a tool.)


Caution: Danger of injury!

2. ASSEMBLY




<p>LETECH winch cover (1x)</p>	<p>Insert the yellow marked noses into the openings of the original bumper.</p>
------------------------------------	---

2. ASSEMBLY



<p>LETECH winch cover (1x)</p>	<p>Insert the yellow marked noses into the openings of the original bumper.</p>
------------------------------------	---

2. ASSEMBLY



Screw M6x25
(2x)

Fasten the LETECH winch cover with the two supplied M6 x 25 hexagon socket screws and tighten to 12 Nm.

(A 5 mm Allen key can be used as a tool.)